


FOOT ACTIVATOR

0011-5446



Optimize water use and maximize play value with Waterplay's on demand button activators. A perfect solutions for reducing water consumption while creating a dynamic play experience. **STEP** to start the flow of water.

See Specification Sheet for product data.



WATER EFFECT

N/A



INSTALLATION

ZERO-DEPTH



EPHASE

DETACHABLE MOUNTING SYSTEM

PLAY OPPORTUNITIES:

It all starts with a touch of a foot! This activator is on the ground for hands-free activation. With a low profile, this activator is perfect for small spaces and encourages users to consider space and place by bringing activity to the ground.



COGNITIVE



SOCIAL



PHYSICAL

Play is fundamental in childhood development, health and wellbeing. Waterplay products are designed using research that supports cognitive, social and emotional, creative and physical growth. The above icons represent the leading attributes associated with this play feature.

PLAY ZONES:



DEVELOPMENT



DISCOVERY



EXPLORATION



ADVENTURE

CATEGORY: Activators

PRODUCT LINE: Freestanding Play & Water Management